ENVIRONMENT OF CARE

This document is a summary of key points as abstracted from the original publication by the PDI Clinical Affairs Team. This summary is intended to be used for educational purposes only. The article may be reviewed in its entirety by accessing through the standard publication process.

Author(s) with institutional affiliation(s): Hajime Kanamori,^{a,b} William A. Rutala,^{a,b} Maria F. Gergen,^a

Emily E. Sickbert-Bennett.^{a,b} David J. Weber.^{a,b}

^a Department of Hospital Epidemiology, University of North Carolina Health Care, Chapel Hill, North Carolina, USA. ^b Division of Infectious Diseases, University of North Carolina School of Medicine, Chapel Hill, North Carolina, USA

Publication Title/Journal/Conference:

Germicidal Activity against Carbapenem/Colistin Resistant Enterobacteriaceae Using a Quantitative Carrier Test Method, Antimicrobial Agents and Chemotherapy - July 2018;62(7):1-5.

Methodology/Study Design: In vitro study

Experiment:

- Susceptibility to germicides (e.g., disinfectants, antiseptics) for carbapenem- or colistin-resistant *Enterobacteriaceae* is poorly described.
- Study assessed the efficacy of multiple germicides against 3 species of *Klebsiella pneumoniae* carbapenemase (KPC)-producing Enterobacteriaceae, including clinical isolates (9) of K. pneumoniae (Kp11), Enterobacter cloacae (Ec12), and a strain of Escherichia coli (ATCC BAA-2340), as well as *E. coli* carrying mcr-1 (MRSN 388634).
- 21 different germicides were tested including:
 - 5 high-level disinfectants/chemical sterilants
 - 7 low- and intermediate-level disinfectants (2 dilutions of sodium hypochlorite)
 - 8 antiseptics, and 1 disinfectant/antiseptic
- A disc-based quantitative carrier test method was used to assess the bactericidal activity of the germicides to produce results similar to those encountered in healthcare settings versus suspension testing.
- An inoculum containing approximately 10⁶ test organisms with 5% fetal calf serum (FCS) was placed on each disk.
- The dried inoculum was exposed to the test germicide for 1 minute exposure time at room temperature then neutralized.

Results:

- Overall, most germicides reached at least 3-log10 reduction (20/22 [91%] for KPC K. pneumoniae, 22/22 [100%] for E. cloacae, 18/22 [82%] for KPC E. coli, 19/22 [86%] for MCR-1 E. coli).
- All germicides, except for 1% chlorhexidine gluconate plus 61% ethyl alcohol and 3% hydrogen peroxide against MCR-1 *E. coli*, demonstrated at least a 2-log10 reduction for these pathogens even in challenging test conditions (5% FCS and 1 min exposure time).
- Super **Sani-Cloth**[®] and **Sani-Cloth**[®] Prime both showed $\geq 4.4 \log 10$ reduction on all 4 organisms.

Conclusions:

• There is no standard level of germicidal efficacy for environmental surfaces, but most germicides tested are likely to be clinically effective (>3-log10 reduction with a margin of safety) against carbapenem/colistin-resistant Enterobacteriaceae when used appropriately.

Limitations:

• The phenotypic and genotypic resistances to germicides were not evaluated.